

EX-3 Expanding Tube Plug



Product Name:

EX-3 Expanding Tube Plug

Part Number:

Refer to Conco Standard Size Chart for EX-3 Expanding Tube Plugs

Application:

For temporary and/or permanent plugging of condenser and heat exchanger tubes.

Description:

- Available for 5/8" O.D. through 1-1/4" O.D. tubes.
- Two each single chloroprene cylinders, grade K2242-CF, ASTM-BC-412 at 45+/shore(s) durometer hardness, expands to seal tube.
- Large outside washer on one end allows plug to fit flush with tubesheet, and not be pulled into tube by vacuum on unit.
- Tested under pressure and vibration to 150 psi and temperature to 200° F

Storage Information:

Store in cool, dry area away from heat and sunlight. Can be kept in sealed plastic bags. Long, undeterminable shelf life.

Auxiliary Equipment Required:

Open end/box wrench.

Determination of Quantity:

Two for each tube to be plugged (one for each end).

Ordering Information:

Contact Conco Services Corporation

530 Jones St.

Verona, PA 15147 USA

Toll free (US Only) 1-800-345-3476 Office +1 412-828-1166 Fax +1 412-826-8255 E-mail info@conco.net

Example Order:

12 Type EX-3 Expanding Tube Plug

7/8" OD x 20 BWG Bronze **Part No. X3Z78**

Availability:

Contact your Conco Representative

Installation¹ Instructions:


- Clean and wipe dry the tube end to be plugged.
- Insert plug into tube into tube until large washer is flush against tubesheet.
- Hand tighten nut finger tight, using open end of box wrench, turn nut 2-3 complete revolutions.
- The end of the bolt is slotted. Use a screwdriver to hold the bolt in place while tightening the nut with a 1/2" (13 mm) box wrench. Tighten to desired torque.

¹See detailed EX-3 Installations on last page



CONCO STANDARD SIZE CHART WITH PART NUMBERS FOR EX-3 EXPANDING PLUGS

O.D.	Brass	Bronze	Stainless	Titanium
5/8"	X3B58	X3Z58	X3Q58	X3T58
3/4"	X3B34	X3Z34	X3Q34	X3T34
7/8"	X3B78	X3Z78	X3Q78	X3T78
1"	X3B11	X3Z11	X3Q11	X3T11
1-1/8"	X3B98	X3Z98	X3Q98	X3T98
1-1/4"	X3B54	X3754	X3Q54	X3T54





Installation steps for Conco EX-3 (expanding) tube plugs

Make sure the tube is clean and dry before attempting to install the plug.

turning in the tube during the final tightening step.

If the tube is dirty, use a bottle brush or a piece of scouring pad to remove the fouling, and then dry the tube. If there is residual water lying in the tube, use a piece of paper towel, foam rubber or rag to "dam up" the water before trying to dry the tube ID. Leaving the piece of paper towel, foam rubber or rag in the tube will not cause any future problems. Once the end of the tube is clean and dry, you are ready to proceed to the next step.

Tighten the nut, to manually expand the plug, until the plug fits snugly in the tube. A snug fit means that the plug needs to be pushed into the tube because it's now slightly larger than the tube. A 7/16" box wrench will help tighten the nut. To determine whether you have expanded the plug enough, try sticking the first section into the tube... if the plug slides in easily, expand it some more. It is important to make sure the plug (EX4 only) fits snugly into the tube to keep it from being sucked down into the tube by the vacuum leak and to prevent the plug from

Push the plug into the tube until the end of the bolt is even with the end of the tube or slightly past the end (outlet end).

If the plug has been sufficiently expanded, it should almost be a tight fit and require some effort to push it into the tube. If it goes in too easily, continue to expand the plug until you have that snug fit.

Using a 7/16" socket, tighten the nut using three complete revolutions (turns) of the wrench, but Do Not Tighten Past This Point! You will be able to "feel" the plug tighten up. In this case, more is not better! If the plug turns in the tube, then remove it and go back to step one. If the tube is clean and dry, the rubber seals will "bite" into the tube and the tightening process will be easily accomplished. Three turns of the wrench is all that will be needed for the plug to be correctly installed. If the plug still turns in the tube... verify that you are using the correct size plug for that tube.

Summary – **clean and dry** is the single most important step in the whole installation process. Expand the tube until it is snug when you push it into the tube. Push the plug in until it is just past the end of the tube and tighten with 3 turns of a 7/16" wrench.

**Double nutting can be done to further insure that the plugs stay tight in the tubes, but it is not required. Simply install a second brass, stainless or titanium nut and tighten... do not overtighten. If the plug does not "feel" tight, remove it and start over.

Tel: 412-828-1166 • Toll-Free: 1-800-345-3476 • Fax: 412-826-8255 • www.conco.net